

# Mettre à jour le firmware

## Etape 0 : Vérification de la version

```
console>enable  
console#show version
```

Pour savoir sur quel partition le switch à démarré :

```
console#show bootvar  
Image   Filename Version    Date          Status  
----  -----  -----  -----  
1     image-1  1.7.1.12 29-Mar-2012 17:51:19 Active*  
2     image-2  1.7.1.12 29-Mar-2012 17:51:19 Not active
```

"\*" designates that the image was selected for the next boot

## Etape 1 : Donner une adresse IP au switch

```
console# configure  
console(config)# interface vlan 1  
console(config-if)# ip address 192.168.10.100 255.255.255.0  
console(config-if)# exit  
console(config)# exit
```

## Etape 2 : Copier les nouveaux fichiers via TFTP sur l'image 2

```
copy tftp://192.168.10.50/alc6224-1.7.1.12.img image-2
```

## Etape 3 : Démarrer sur l'image 2

```
console# boot system image-2  
console# reload
```

## Etape 4 : Copier les nouveaux fichiers via TFTP sur l'image 1

```
console# copy tftp://192.168.10.50/alc6224-1.7.1.12.img image-1
```

## Etape 5 : Démarrer sur l'image 1

```
console# boot system image-1  
console# reload
```

## Etape 6 : Vérification

```
console#show bootvar  
Image   Filename  Version    Date          Status  
----  -----  -----  -----  
1     image-1   1.7.1.12  29-Mar-2012 17:51:19  Active*  
2     image-2   1.7.1.12  29-Mar-2012 17:51:19  Not active
```

"\*" designates that the image was selected for the next boot

---

Revision #1

Created 12 March 2024 11:54:22 by Dunnload

Updated 12 March 2024 11:54:30 by Dunnload