

Mettre à jour le firmware

Etape 0 : Vérification de la version

```
console>enable
console#show version
```

Pour savoir sur quel partition le switch à démarré :

```
console#show bootvar
Image  Filename      Version      Date                Status
-----  -
1      image-1          1.7.1.12    29-Mar-2012  17:51:19  Active*
2      image-2          1.7.1.12    29-Mar-2012  17:51:19  Not active

"*" designates that the image was selected for the next boot
```

Etape 1 : Donner une adresse IP au switch

```
console# configure
console(config)# interface vlan 1
console(config-if)# ip address 192.168.10.100 255.255.255.0
console(config-if)# exit
console(config)# exit
```

Etape 2 : Copier les nouveaux fichiers via TFTP sur l'image 2

```
copy tftp://192.168.10.50/alc6224-1.7.1.12.img image-2
```

Etape 3 : Démarrer sur l'image 2

```
console# boot system image-2
console# reload
```

Etape 4 : Copier les nouveaux fichiers via TFTP sur l'image 1

```
console# copy tftp://192.168.10.50/alc6224-1.7.1.12.img image-1
```

Etape 5 : Démarrer sur l'image 1

```
console# boot system image-1
console# reload
```

Etape 6 : Vérification

```
console#show bootvar
Image  Filename  Version  Date                Status
-----  -
1      image-1    1.7.1.12  29-Mar-2012  17:51:19  Active*
2      image-2    1.7.1.12  29-Mar-2012  17:51:19  Not active

"*" designates that the image was selected for the next boot
```

Revision #1

Created 12 March 2024 11:54:22 by Dunnload

Updated 12 March 2024 11:54:30 by Dunnload