

[PBX PLUG 1xx] Commandes

Voir les log des ports BRI / PRI

```
vxTarget# debug isdn all layer 2-3 full  
vxTarget# monitor loggin
```

Etat du trunk sip

```
vxTarget# show voice sip-gateway
```

Revision #1

Created 28 February 2025 08:03:19 by Dunnload

Updated 28 February 2025 08:05:09 by Dunnload