

Supprimer la configuration

Pour supprimer la configuration :

```
-> cd working  
-> rm vcboot.cfg  
-> cd ..  
-> cd certified  
-> rm vcboot.cfg  
-> reload from working no rollback-timeout
```

Revision #1

Created 10 March 2024 12:41:06 by Dunnload

Updated 10 March 2024 12:41:16 by Dunnload