

# Supprimer la configuration

Pour supprimer la configuration :

```
-> cd working
-> rm vcboot.cfg
-> cd ..
-> cd certified
-> rm vcboot.cfg
-> reload from working no rollback-timeout
```

---

Revision #1

Created 10 March 2024 12:41:06 by Dunnload

Updated 10 March 2024 12:41:16 by Dunnload