

Configuration du DHCP

DHCP Relay

```
ProCurve Switch 2650(config)# vlan 101
ProCurve Switch 2650(vlan-101)# ip helper-address 192.168.1.199
```

Avec option 82

```
ProCurve Switch 2650(config)# dhcp-relay option 82
```

append	Specifies that the option 82 field should be appended to client DHCP packet.
drop	Specifies that the DHCP packet will be dropped unconditionally, if option 82 field(s) already exists in the client DHCP packet.
keep	Specifies that no option 82 field will be added or replaced, if option 82 field(s) already exists in the client DHCP packet.
replace	Specifies that any existing option 82 fields will be replaced with switch option 82 field for client DHCP packet.
validate	Specifies the validation for server response.

DHCP Snooping

Activation

```
ProCurve Switch 2650(config)# dhcp-snooping
```

Autoriser un serveur DHCP

```
ProCurve Switch 2650(config)# dhcp-snooping authorized-server 192.168.1.200
```

Activation sur un vlan

```
ProCurve Switch 2650(config)# dhcp-snooping vlan 200
```

Vérification

ProCurve Switch 2650# show dhcp-snooping

ProCurve Switch 2650# show dhcp-snooping stats

Revision #1

Created 11 March 2024 17:30:17 by Dunnload

Updated 11 March 2024 17:30:27 by Dunnload